



---

# Management of Beryllium at AWE Aldermaston

Clive Le Gresley

[Clive.W.LeGresley@awe.co.uk](mailto:Clive.W.LeGresley@awe.co.uk)

[www.awe.co.uk](http://www.awe.co.uk)

## Spring BHSC meeting 2013, ORAU - ORISE

Any reference to products, companies, persons or organisations is for information purposes only and does not represent any form of endorsement or criticism. Opinions expressed here are those of the author only and do not represent those of AWE.



# **Facility Remit**

- To manage the AWE Be stockpile on behalf of MoD.
- To manufacture Be components for Service, Trials and R&D.
- These operations must be conducted safely and in accordance with agreed procedures.
- Operating Philosophy –
  - To prevent exposure to Be particulate by airborne and dermal routes
  - Assume 100% success of HVAC, and investigate ALL excursions.

## **Be processing areas**

- **Controlled:**
  - “High” risk of airborne Be particulate.
  - Engineered HVAC system.
  - Use of a physical access barrier.
  - Wear coveralls, PAS etc.
  
- **Supervised:**
  - “Low” risk of airborne Be particulate.

# Change barrier





# HVAC design philosophy

- It had been identified in the 1920s/30s that Be could cause respiratory problems.
- Therefore, when AWE was being built, the decision was made to treat Be identically to R/A materials, ie


Be processing operations would be fully contained within extracted enclosures.

# **Ventilation system**

- Hierarchical – based on the processing hazard;
  - HPE – Gloveboxes (powder handling)
  - HVE – Tool tip swarf capture
  - LPE – Enclosures (general containment)
  - Plenum – supply air (heating and cooling)
- All ventilation plant – motors/fans/filters – in one plant room.
- A sampling system downstream of the (HEPA) filters allows quantification of airborne discharges – a Regulatory requirement.



# Lathe containment – “then”





# Lathe containment – “now”



Old TC1  
(c. 1990)




New Production and  
Samples lathes (c.2011)

## Material Box - Glovebox side



# Mill Fixturing + HVE






## Vibrophone and Instron Tensile Tester



# Ultrasonic Vapour Degreaser



# CMM



# **Data recording**

- Four data fields recorded;
  - Personal Air Samplers (PASs)
  - Stack emissions – Regulatory requirement.
    - Discharge limit =  $0.5 \mu\text{g m}^{-3}$ .
  - Surface smears.
  - Static Air Samplers (SASs)



## Summary of PAS data: 01/01/97 – 31/12/12

	PAS reading - $\mu\text{g m}^{-3}$					
TOTAL	$\leq 0.02$	$\leq 0.1$	$\leq 0.5$	$\leq 1.0$	$\leq 2.0$	$> 2.0$
113032	111733	1234	57	4	2	2
% of total	98.85	1.092	0.05	0.004	0.002	0.002

# Responses to excursions

- Airborne: ( $\mu\text{g m}^{-3}$ )
  - $> 0.02$  (SAS) – local investigation
  - $\geq 0.25$  (PAS) – formal local investigation
  - $\geq 0.5$  (PAS) – suspend operation, formal local investigation.
  
- Surface: ( $\mu\text{g ft}^{-2}$  (!))
  
- Company guidance wrt levels;
  - $\leq 1$  – Movement OK to a white area
  - $\leq 5$  – Movement OK within a yellow (Be designated) area
  
- On the basis of operational history, a local management decision has been taken to reduce all working levels to that of a non-controlled Be area i.e  $< 1.0 \mu\text{g/ft}^2$  ( $10.0 \mu\text{g/m}^2$ ).



# **CONCLUSIONS**

- Primary concern is prevention of exposure to airborne Be particulate by inhalation.
- This achieved by;
  - Processing Be at workstations with extract ventilation,
  - Adopting rigorous procedural controls,
  - Assuming 100% success of the containment, and
  - Investigating ALL excursions.
- This approach shown to work by the Health Physics – PAS/SAS – data generated.
- This conclusion – based on AWE(A) operations – is confirmed by earlier AWE(C) operational Health Physics data.
- Since 1979, using this approach, in conjunction with our OH/Medical procedures, there have been no notified cases of CBD.